RSFQ DRIVEN CAVITY PHOTON NUMBER

MATTHEW BECK

Here we describe how to back out cavity photon number for a steady train of RSFQ Pulses. We start by calculating the input power for an RSFQ pulse.

$$P_{\rm in} = P_{\rm App}/Q_c = P_{\rm App} \times \frac{\omega C_c^2 R_l}{C_T},\tag{1}$$

Where $P_{\rm App}$ is the applied power at the resonator input, ω is frequency, R_l is the load impedance, and C_c and C_T are the coupling and total capacitance, respectively. Now, the applied power, $P_{\rm app}$ can be calculated as follows

$$P_{\rm App} = \frac{V^2}{R_l} \tag{2}$$

Inserting (2) into (1) yields

$$P_{\rm in} = \frac{\omega C_c^2 V^2}{C_T} \tag{3}$$

We can now define the voltage of the SFQ pulse in terms of the magnetic flux quantum and the drive frequency

$$V_{\rm SFQ} = \Phi_0 \times \omega \tag{4}$$

inserting (4) in (3)

$$P_{\rm in} = \frac{\omega^3 C_c^2 \Phi_0^2}{C_T} \tag{5}$$

If we then define Power as $P = E \times \omega$ we then find that we arrive at the same energy per pulse calculated by Robert McDermott, et al in *Accurate Qubit Control* with Single Flux Quantum Pulses, PRA (2014) modulo a factor of 2.

$$E_{\rm in} = \frac{P_{\rm in}}{\omega} = \frac{\omega^2 C_c^2 \Phi_0^2}{C_T} \tag{6}$$

$$E_{\rm in}^{\rm McDermott} = \frac{1}{2} \times \frac{\omega^2 C_c^2 \Phi_0^2}{C_T} \tag{7}$$

Date: May 12, 2016.

I am assuming this factor of 2 comes from some averaging not explicitly stated in the McDermott paper. Now that we have the power leaking into the cavity, we can now calculate the average photon number using the relation

$$\bar{n} = P_{\rm App} \left(\frac{Q_T^2}{Q_c \hbar \omega^2} \right) = P_{\rm in} \left(\frac{Q_T^2}{\hbar \omega^2} \right)$$
 (8)